


SK NÁVOD NA MONTÁŽ
 CZ MONTÁŽNÍ NÁVOD
 HU SZERELÉSI UTASÍTÁS
 DE MONTAGEANLEITUNG

RACHEL PANEL






	540	mm
	1918	
	300	









09262	②	538*284*22	1x	1/1
09263	③	1918*340*16	1x	1/1
09264	④	1918*200*16	1x	1/1




27000,00	22705,00	22300,00	22400,00	22501,02	70013,01	70021,01	36517,00	31022,00	31023,00										
Ø8x30		Ø7x50	M4x30	M4x20															
A	6x	B	4x	C	3x	D	1x	E	5x	F	4x	G	4x	H	2x	J	1x	K	2x

		55 min		PZ2	4		3m	600 mm	



									
A	6x	B	4x	F	4x	G	4x	H	2x





Ø7x50


C 3x



M4x30



M4x20



J 1x




K 2x


D 1x

E 5x

J 1x

K 2x





2. 440mm

